

Compatibility List for Canon USB Devices

Last Updated January, 26th 2012

Please always make sure to use the latest Silex firmware and software and the latest Canon printer driver. If your Canon device is a multifunction printer please use the latest SX-Virtual Link software.

Free download: <http://www.silexeurope.com/en/home/support/overview.html>

Quick Overview

Silex Device	Device Type	Canon Device	Device Interface Speed Full Speed = 12 Mbit/s Hi-Speed = 480 Mbit/s Wired = 10BaseT, 100Base-TX	Network Interface Type Wired = 10BaseT, 100Base-TX Wireless = 802.11b/g	MSRP (Manufacturer Suggested Retail Price)
C-6600GB	Scan- & Print Server	1 x USB	Hi-Speed	Wired only (Gigabit)	105,00 €
C-6700WG	Print Server	1 x USB	Hi-Speed	Wired / Wireless	129,00 €
SX-3000GB	USB Device Server	2 x USB	Hi-Speed	Wired only (Gigabit)	115,00 €
SX-DS-4000U2	USB Device Server	2 x USB	Hi-Speed	Wired only (Gigabit)	149,00€
SX-2000WG	USB Device Server	1 x USB	Hi-Speed	Wired + Wireless	158,00 €
SX-2500CG	Wireless Ethernet Adapter Home / office	USB + Wired	Wired	Wireless only	99,00 €
SX-600	Wireless Ethernet Adapter Industrial	USB + Wired	Wired	Wireless only	179,00 €

Scanners

Canon USB Scanner	C-6600GB	SX-DS-4000U2	SX-2500CG SX-600
CR-50	✓	✓	X
DR-2010C	✓	✓	X
DR-2010M	✓	✓	X
DR-2020U	X	✓*8	X
DR-2510C	✓	✓	X
DR-2510M	✓	✓	X
DR-2580C	✓	✓	X
DR-3010C	✓	✓	X
DR-4010C	✓	✓	X
DR-6010C	✓	✓	X
DR-6050C	✓	✓	X
DR-7550C	✓	✓	X
DR-9050C	✓	✓	X
DR-C125	✓	✓	X
DR-X10C	✓	✓	X
DR-M160	✓	✓	X
DR-M140	✓	✓	X
DR-M140 and flatbed unit 101	X	✓	X
P150	✓	✓	X
P150M	✓	✓	X
P215	✓	✓	X
ScanFront 300	-	-	✓

✓ = Compatible
X = Not Compatible
- = Not Tested

ScanFront 300P	-	-	✓
----------------	---	---	---

Laser Printers

Canon USB Device	C-6700WG C-6600GB	SX-2000WG SX-3000GB SX-DS-4000U2	SX-2500CG SX-600
i-SENSYS MF5980dw	✓	✓	✓
i-SENSYS MF5940dn	✓	✓	✓
i-SENSYS MF3010	✓	✓	X
LBP2410	✓	✓	X
LBP2900	✓	✓	X
LBP2900B	✓	✓	X
LBP3000	✓	✓	X
LBP3010	✓	✓	X
LBP3010B	✓	✓	X
LBP3100	✓	✓	-
LBP3250	✓	✓	X
LBP3300	✓	✓	✓*0
LBP3310	✓	✓	✓*0
LBP3360	✓	✓	✓
LBP3370	-	-	✓
LBP3460	-	-	✓
LBP5000	✓	✓	✓*0
LBP5050	✓	✓	-
LBP5050N	✓	✓	✓
LBP5100	✓	✓	✓*0
LBP5300	✓	✓	✓
LBP5200	✓	✓	X
LBP5360	-	-	✓
MF4010	✓	✓	X
MF4012	✓	✓	X
MF4018	✓	✓	X
MF4120	✓	✓	X
MF4140	✓	✓	X
MF4150	✓	✓	X
MF4270	-	-	✓
MF4320d	✓	✓	X
MF4330d	✓	✓	X
MF4340d	✓	✓	X
MF4350d	✓	✓	X
MF4370dn	✓	✓	✓
MF4380dn	✓	✓	✓
MF4410	✓	✓	X
MF4430	✓	✓	X
MF4450	✓	✓	X
MF4450d	✓	✓	X
MF4660	-	-	✓
MF4690PL	-	-	✓
MF6530	✓	✓	X
MF6540PL	✓	✓	X

✓ = Compatible
 X = Not Compatible
 - = Not Tested

MF6550	✓	✓	X
MF6560PL	✓	✓	X
MF6580PL	✓	✓	✓
MF8180C	-	✓	✓
MF8450	-	-	✓
MF9130	-	-	✓
MF9170	-	-	✓
PC-D320	-	-	-
PC-D340	-	-	-
PC-D450	✓	✓	X
FAX-L160	-	-	-
FAX-L380S	-	-	-
FAX L390	-	-	-
FAX-L3000	-	-	-
FAX-L3000IP	-	-	✓

InkJet Printers

Canon USB Device	C-6700WG C-6600GB	SX-2000WG SX-3000GB SX-DS-4000U2	SX-2500CG SX-600
BJ 535PD	✓	✓	X
BJ 895PD	✓	✓	X
BJ F210	✓	✓	X
BJ F300	✓	✓	X
BJ F360	✓	✓	X
BJ F610/F620	✓	✓	X
BJ F6100	✓	✓	X
BJ F620	✓	✓	X
BJ F660	✓	✓	X
BJ F6600	✓	✓	X
BJ F850	✓	✓	X
BJ F860	✓	✓	X
BJ F870	✓	✓	X
BJ F870PD	✓	✓	X
BJ F890PD	✓	✓	X
BJ F900	✓	✓	X
BJ F9000	✓	✓	X
BJ F930	✓	✓	X
BJ M40	✓	✓	X
BJ M70	✓	✓	X
BJ S200	✓	✓	X
BJ S300	✓	✓	X
BJ S330	✓	✓	X
BJ S500	✓	✓	X
BJ S530	✓	✓	X
BJ S600	✓	✓	X
BJ S700	✓	✓	X
BJ S630	✓	✓	X
BJ F890PD	✓	✓	X
BJ F860	✓	✓	X
BJ F930	✓	✓	X

✓ = Compatible
X = Not Compatible
- = Not Tested

BJC-2100	✓	✓	X
BJC-2100SP	✓	✓	X
Canon USB Device	C-6700WG C-6600GB	SX-2000WG SX-3000GB SX-DS-4000U2	SX-2500CG SX-600
BJC-3000	✓	✓	X
BJC-55	✓	✓	X
BJC-6100	✓	✓	X
BJC-6200	✓	✓	X
BJC-6500	✓	✓	X
BJC-8200	✓	✓	X
BJC-85	✓	✓	X
CX350	✓ *3	✓ *3	X
i320	✓	✓	X
i450	✓	✓	X
i455	✓	✓	X
i470D	✓	✓	X
i475D	✓	✓	X
i550	✓	✓	X
i560	✓	✓	X
i6100	✓	✓	X
i6500	✓	✓	X
i50	✓	✓	X
i70	✓	✓	X
i80	✓	✓	X
i850	✓	✓	X
i860	✓	✓	X
i865R	✓	✓	X
i900D/i905D	✓	✓	X
i9100	✓	✓	X
i950	✓	✓	X
i960	✓	✓	X
i965	✓	✓	X
i990	✓	✓	X
i9900	✓	✓	X
i9950	✓	✓	X
iP90	✓	✓	X
iP100	✓	✓	X
iP1180	✓	✓	X
iP1300	✓	✓	X
iP1200	✓	✓	X
iP1500	✓	✓	X
iP1600	✓	✓	X
iP1700	✓	✓	X
iP1800	✓	✓	X
iP1900	✓	✓	X
iP2000	✓	✓	X
iP2500	✓	✓	X
iP2600	✓	✓	X
iP2700/iP2702	✓	✓	X
iP3000	✓	✓	X
iP3100	✓	✓	X
iP3300	✓	✓	X
iP3500	✓	✓	X

✓ = Compatible
 X = Not Compatible
 - = Not Tested

iP3600	✓	✓	X
iP4000	✓	✓	X
Canon USB Device	C-6700WG C-6600GB	SX-2000WG SX-3000GB SX-DS-4000U2	SX-2500CG SX-600
iP4100	✓	✓	X
iP4200	✓	✓	X
iP4300	✓	✓	X
iP4500	✓	✓	X
iP4600	✓	✓	X
iP4700/iP4760	✓	✓	X
iP4840	✓	✓	X
iP4850	✓	✓	X
iP4950	✓	✓	X
iP5000	✓	✓	X
iP5200	✓	✓	X
iP5300	✓	✓	X
iP6000D	✓	✓	X
iP6100D	✓	✓	X
iP6210D	✓	✓	X
iP6220D	✓	✓	X
iP6310D	✓	✓	X
iP6320D	✓	✓	X
iP6600D	✓	✓	X
iP6550	✓	✓	X
iP6700D	✓	✓	X
iP7100	✓	✓	X
iP8100	✓	✓	X
iP8500	✓	✓	X
iP8600	✓	✓	X
iP9910	✓	✓	X
iX4000	✓	✓	X
iX5000	✓	✓	X
iX6550/6540	✓	✓	X
MG2150	✓	✓	X
MG3150	✓	✓	X
MG5140/50	✓	✓	X
MG5350	✓	✓	X
MG6250	✓	✓	X
MG8250	✓	✓	X
MP140	✓	✓	X
MP160	✓	✓	X
MP150	✓	✓	X
MP170	✓	✓	X
MP180	✓	✓	X
MP190	✓	✓	X
MP210	✓	✓	X
MP220	✓ *5	✓ *5	X
MP240	✓ *5	✓ *5	X
MP252	✓	✓	X
MP250/258	✓	✓	X
MP260	✓ *4,5	✓ *4,5	X
MP270/276	✓	✓	X
MP280/282	✓	✓	X

✓ = Compatible
 X = Not Compatible
 - = Not Tested

MP360	✓ *5	✓ *5	X
MP370	✓ *5	✓ *5	X
Canon USB Device	C-6700WG C-6600GB	SX-2000WG SX-3000GB SX-DS-4000U2	SX-2500CG SX-600
MP390	✓	✓	X
MP460	✓	✓	X
MP470	✓	✓	X
MP492	✓	✓	X
MP480	✓*4,5	✓*4,5	X
MP490/496	✓	✓	X
MP500	✓	✓	X
MP510	✓	✓	X
MP520	✓ *5	✓ *5	X
MP540	✓ *4	✓ *4	X
MP530	✓	✓	X
MP550/558	✓	✓	X
MP560/568	✓	✓	X
MP600	✓	✓	X
MP610	✓ *5	✓ *5	X
MP620	✓ *5	✓ *5	X
MP630	✓ *4	✓	X
MP700	✓	✓	X
MP710	✓ *2	✓ *2	X
MP730	✓ *2	✓ *2	X
MP740	✓	✓	X
MP750	✓	✓	X
MP760	✓	✓	X
MP770	✓	✓	X
MP780	✓	✓	X
MP790	✓ *5	✓ *5	X
MP800	✓	✓	X
MP810	✓	✓	X
MP830	✓	✓	X
MP865R	✓	✓	X
MP900	✓	✓	X
MP950	✓	✓	X
MP960	✓	✓	X
MP970	✓	✓	X
MP980	✓ *4	✓ *4	X
MX300	✓	✓	X
MX310	✓ *7	✓ *7	X
MX320	✓	✓	X
MX360	✓	✓	X
MX410	✓	✓	X
MX700	✓	✓	X
MX7600	✓	✓	X
MX850	✓	✓	X
Pro9000	✓	✓	X
Pro9500MkII	✓	✓	X
Pro9500	✓	✓	X
Pro9000MkII	✓	✓	X
S100	✓	✓	X
S200	✓	✓	X

✓ = Compatible
 X = Not Compatible
 - = Not Tested

S300	✓	✓	X
S330	✓	✓	X
Canon USB Device	C-6700WG C-6600GB	SX-2000WG SX-3000GB SX-DS-4000U2	SX-2500CG SX-600
S400	✓	✓	X
S450	✓	✓	X
S4500	✓	✓	X
S500	✓	✓	X
S520	✓	✓	X
S530D	✓	✓	X
S600	✓	✓	X
S630	✓	✓	X
S6300	✓	✓	X
S750	✓	✓	X
S800	✓	✓	X
S820	✓	✓	X
S820D	✓	✓	X
S830D	✓	✓	X
S900	✓	✓	X
S9000	✓	✓	X

*0 = With Canon Network Option.

*2 = This model does not support PC fax function.

*3 = This model does not support Windows 98, because the printer driver is not available.

*4 = Access to card reader with MP Navigator EX not available for Windows 2000.

*5 = Special Setting function of the driver utility not available.

*7 = ADF scanning stops at the second page by Windows XP "OS standard Scanner and Camera Wizard."

*8 = Scanbuttons on device are not supported

Note: All devices are tested only on Windows. Mac OS might also work but is not tested.

✓ = Compatible
X = Not Compatible
- = Not Tested